

EVERYTHING EXPLAINED for the Professional Pilot

CLASS A Airspace: (71.1, 71.31, 71.33, 71.75, 71.133, 91.135, 91.155, AIM 3-2-1, 3-2-2)

- <u>All</u> airspace from <u>18,000</u> feet up to and including <u>FL 600</u> within the 48 contiguous States (including the District of Columbia) and most of Alaska plus the airspace within 12 NM offshore.
- There is no Class A airspace over Hawaii and the Victor airways have no upper limit in Hawaii.
- 2. All aircraft MUST be IFR unless otherwise authorized. No VFR (unless for purposes of lost communications).
- 3. No minimum flight visibility or distance from clouds is specified.
- 4. Altimeter setting for all aircraft **<u>29.92</u>** (in US controlled airspace).

CLASS B Airspace: (71.41, 91.117, 91.126, 91.127, 91.129, 91.130, 91.131, 91.155, 91.215, AIM 3-2-1, 3-2-3)

- 1. Surface to 7,000 feet or up to 12,500 feet surrounding the nation's busiest airports.
- 2. Individually tailored upside-down wedding cakes contain all instrument approaches.
- 3. <u>Clearance into Class B required</u>. (91.131, Letter of Interpretation from Office of Chief Counsel dated Jan 10, 2010)
- 4. VFR operations <u>3 miles</u> <u>Clear of Clouds</u> and at least a <u>1,000 ft ceiling</u> (or Special VFR).
- 5. IFR operations An operable <u>VOR</u> or TACAN receiver is required. (91.131)
- Unless otherwise authorized by ATC, a <u>LARGE TURBINE-POWERED</u> airplane operating to or from a primary airport in Class B airspace <u>MUST operate AT</u> or <u>ABOVE</u> the <u>FLOORS</u> of the <u>Class B</u> airspace while within the lateral limits of that area <u>even when</u> operating on a <u>visual approach</u>.
- A <u>LARGE</u> (12,500 lbs or more) <u>or TURBINE-POWERED</u> airplane shall, unless otherwise required by distance from cloud criteria, enter the <u>TRAFFIC PATTERN</u> at an altitude of at least <u>1,500 feet AGL</u> and maintain 1,500 AGL until further descent is required for a safe landing. [Noise abatement]
- 8. A <u>large</u> or <u>turbine-powered</u> airplane approaching to land on a runway served by an <u>ILS</u> shall fly <u>at or</u> <u>above</u> the <u>GLIDE SLOPE between</u> the <u>outer marker</u> and the <u>middle marker</u>.
- Any airplane approaching to land on a runway served by a VASI shall maintain at or above the glide slope (aka glide path) until a lower altitude is necessary for a safe landing.
- 10. <u>Mode C veil</u> All aircraft operating within <u>30 NM</u> of a Class B airport, from the surface to 10,000 feet must have Mode C (unless the aircraft was originally certified without an electrical system and still does not have one).
- 11. SPEED LIMIT 250 KIAS below 10,000 feet (200 KIAS below the floor or in VFR corridor).
 - a. <u>250 KIAS MUST NOT BE EXCEEDED even if</u> you are told to "<u>MAINTAIN BEST FORWARD</u> <u>SPEED</u>."
 - b. "<u>Maintain best</u> (or maximum) <u>forward speed</u>" means "maximum or best forward *<u>LEGAL</u>* speed." ATC does not have the authority to lift the 250 below 10,000 ft speed restriction [91.117(a)]. <u>You cannot be cleared to violate a regulation</u>, and you cannot accept such a clearance.
 - c. If a controller assigns you 300 kts or greater inbound (10,000 ft or above), and he later descends you to 8,000 ft, it is <u>UNDERSTOOD</u> that you must <u>slow to 250 KIAS BEFORE</u> descending below 10,000.

т <u>п</u>	t or above the glide slope" does not prohibit <u>normal bracketing</u> <u>naneuvers above or below</u> the <u>glide slope</u> for the purpose of remaining on the glide slope. Normal bracketing maneuvers are maneuvers which remain within the <u>limits</u> of the <u>higher</u> and <u>lower</u> <u>glide slope signals</u> . D airspace — or within <u>Class E</u> airspace when within <u>35 miles</u> of the <u>destination</u> .
	·····
1	Do you have to hear the words "Cleared into Class B" when VFR?
1.	The short answer is <u>ves</u> . You must hear the word " <u>cleared</u> " at least somewhere in the instructions given to you by the approach controller. Radar identification and instructions to maintain a specific altitude and heading that will put you in their airspace can no longer be considered an implicit, implied, or understood clearance into Class B (although it happens <i>all</i> the time). A Letter of Interpretation addressed to my friend Bridgette Doremire from the Office of Chief Counsel dated January 10, 2010 serves to rescind previous policy.
2.	So if you can get a word in edgewise, <u>always</u> ask for confirmation, just to get it on the tape.
3.	That being said if you've been radar identified by the approach control having jurisdiction (e.g.; Charlotte
	<u>Approach</u> ; "flight following" from "center" will <i>not</i> clear you anywhere); the terms "cleared as requested" or even "proceed as requested" or a clearance to a specific point inside the Class B will also suffice. Example: "Citation 5CM radar contact, cleared direct Charlotte, climb and maintain four thousand, expect 36R."

91.131 [Operations in Class B airspace] (a)(1) — "The operator <u>must receive</u> an <u>ATC clearance</u> from the ATC facility having jurisdiction for that area <u>before operating</u> an aircraft <u>in that area</u>." It <u>does NOT say</u> — "The operator <u>must</u> specifically <u>hear</u> the <u>magic words</u> <u>'Cleared into Class B</u>'..." If the frequency is totally saturated and you're truly paranoid about the magic words, then turn around and run away. Now <u>that</u> will get their attention!:o)

......

EVERYTHING EXPLAINED for the Professional Pilot

CLASS E Airspace:

- (71.71, 91.127, 91.155, 135.205, AIM 3-1-4, 3-2-1, 3-2-5, 3-2-6, 4-1-18, 4-3-26, 4-4-12, 5-5-6, FAA-H-8083-15A, FAA-H-8083-25A)
 - 1. **<u>CONTROLLED</u>** airspace that is not Class A, B, C, or D within the 48 contiguous States and Alaska.
 - 2. Generally the <u>upward limit</u> is <u>18,000 feet</u>. NOTE: <u>Class E</u> airspace <u>begins again</u> above <u>FL 600</u>.
 - 3. Types of Class E:
 - A <u>SURFACE AREA</u> designated for an <u>AIRPORT</u> designed to contain all instrument approaches. The primary requirements for a Class E airport are approved <u>weather reporting</u> (FSS or ASOS/AWOS) and a means of <u>communications with ATC</u> all the way to the ground.
 - b. **EXTENSIONS** to a **SURFACE AREA** of **Class B, C, or D** airspace to contain instrument approaches.
 - c. TRANSITION AREAS beginning at either 700 or 1,200 ft AGL, used to/from the en route environment.
 - d. **EN ROUTE AREAS** that provide **controlled airspace** for **IFR** but are **NOT Federal airways**.
 - e. Federal AIRWAYS from 1,200 AGL upward to but not including 18,000 MSL.
 - f. Unless designated at lower altitude—<u>Class E begins</u> at <u>14,500 MSL</u> up to, but not including, <u>18,000 MSL</u>.

OpSpec C077 requires <u>commercial operators</u> to <u>remain within Class B, C</u>, or <u>D</u>

airspace — or within Class E airspace when within 35 miles of the destination.


VFR in CLASSE (controlled) Airspace:

(91.155, 91.157, AIM 3-1-4, 3-2-6, 5-4-22, FAA-H-8083-15A, FAA-H-8083-25A, OpSpec C077)

- 1. <u>Less than 10,000</u> feet MSL <u>3 SM</u> visibility Cloud separation: 500 below, 1,000 above, 2,000 horizontally.
- <u>At or above 10,000</u> feet MSL <u>5 SM</u> visibility Cloud separation: 1,000 below, 1,000 above, 1 mile horizontally.
- No person may operate an aircraft <u>beneath</u> the <u>ceiling</u> under VFR within the limits of controlled airspace designated to the surface for an airport <u>when</u> the <u>ceiling</u> is <u>less than 1,000 feet</u> (except "Special VFR" 91.157).
- NOTE #1: <u>Do NOT cancel in the air</u> while on approach to an airport with a <u>Class E</u> surface area <u>unless</u> the weather meets the basic <u>VFR weather</u> and <u>cloud separation</u> requirements of 91.155 (see 1. above) unless you have received a "Special VFR" clearance (91.157).
- 5. NOTE #2: A "<u>Special VFR</u>" clearance is <u>treated almost</u> the <u>same as an IFR</u> clearance as far as separation is concerned. It is <u>not likely to save you or</u> the <u>guy behind you any time</u>. So, if the weather is <u>below 3 miles visibility</u> and/or the <u>ceiling</u> is <u>below 1,000</u> ft or there's a chance that <u>cloud</u> <u>separation</u> could be a problem, <u>just wait till you're on</u> the <u>ground to cancel</u>. You never know who might be lurking in the weeds just waiting for a chance to make your life miserable.
- NOTE #3: To conduct a <u>VISUAL APPROACH</u> in Class B, C, D, or E airspace under <u>Part 91</u> you need only maintain "<u>clear of clouds</u>" (AIM 5-4-22). <u>Part 135</u> (turbojets) and <u>Part 121</u> are restricted by OpSpec C077 and <u>must maintain</u> the <u>cloud separation required by 91.155</u> (see 1. above).

SURFACE-BASED CLASS E: (AC 90-66A, FAA-H-8083-3, FAA-H-8083-15A, FAA-H-8083-25A)

- 1. <u>Brings</u> Class E, <u>controlled airspace</u>, <u>to the surface</u> in order to raise the weather minimums and <u>restrict VFR traffic</u> during poor weather. Especially important for <u>ILS approaches</u>.
- 2. Must have approved weather reporting and communications with ATC to the surface.
- 3. The airport manager must also request and receive Class E approval from the FAA.
- 4. Most airports with weather reporting and communications with ATC never request Class E status because it would make VFR traffic illegal when the visibility drops below 3 SM and/or ceiling below 1,000 feet. Not good for business, especially if there's a flight school on the field.
- 5. When weather reporting is unavailable, Class E reverts to Class G with a Class E transition area.
- 6. Represented by dashed lines on sectionals and enroute charts.
- 7. Surface-based Class E was formerly known as a control zone.
- 8. "<u>RECOMMENDED</u>" traffic pattern <u>SPEED LIMIT</u> is <u>200 kts</u>.



EVERYTHING EXPLAINED for the Professional Pilot